

Work Order ID 80971

80971

Page 1

March-06-12 9:13:01 AM

Item ID: D206-642-113

Accept

N900040100

Setup Start *NS1*

Revision ID:

Stop *NS2*

Item Name: Skidtube LH

Start Date: 06/03/2012 Start Qty: 1.00

1

Cust Item ID:

Required Date: 20/03/2012 Req'd Qty: 1.00

1

Customer:

Reference:

Approvals: Process Plan: MLS

Date: 12/03/06

Tooling:

Date:

Run Start *NR1*

QC:

Date:

SPC (Y/N):

Date:

Stop *NR2*

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
--------------------------------	--------------------------	----------------------	---------	--------	--------------	---------------	---------------	------------------	----------------

Draw Nbr

Revision Nbr

IIN-D206-642

0

100

100

DOCUMENT CONTROL

0.00

DC

Memo

0.00

Document Control

Photocopy bluefile & type labels per PPP206-642-113 CHG002
K10111 CHG003

110

Pick Kit

0.00

110

Packaging

Memo

0.00

Packaging

120

QC4- 100% Inspect kits for completeness

0.00

120

QC

Memo

0.00

Quality Control

1380855 L+1

12-3-30

12/3/30

ⓧ

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries

Work Order ID 80971

80971

Page 2

March-06-12 9:13:01 AM

Item ID: D206-642-113

Accept

N900040100

Setup Start ***NS1***

Revision ID:

Item Name: Skidtube LH

Stop ***NS2***

Start Date: 06/03/2012 Start Qty: 1.00

1

Cust Item ID:

Required Date: 20/03/2012 Req'd Qty: 1.00

1

Customer:

Reference:

Approvals:

Process Plan:

Date:

Tooling:

Date:

Run Start ***NR1***

QC:

Date:

SPC (Y/N):

Date:

Stop ***NR2***

Sequence ID/ Work Center ID	Operation Description	Set Up/ Run Hours	Tool ID	Tool #	Plan Code	Accept Qty	Reject Qty	Reject Number	Insp. Stamp
130	Packaging	0.00							
130									
Packaging	Memo	0.00							
Packaging	Identify and pack for shipping as per PPPD206-642-113								
	K10111								
	Location: <u>ARM</u>								
	PPP Rev: <u>B</u>								
140	QC21- Final Inspection - Work Order Release	0.00							
140									
QC	Memo	0.00							
Quality Control									

KSP 12-04-10

12/4/12

12-04-11

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries

Picklist Print

March-06-12 9:13:05 AM

Page 1

Work Order ID: 80971

80971

Parent Item: D206-642-113

D206-642-113

Parent Item Name: Skidtube LH

Start Date: 06/03/2012

Required Date: 20/03/2012

Start Qty: 1.00

Required Qty: 1.00

Comments: IPP REV:A 10.12.08 PER REV.N DD VERF:EC IPP
REV:B 11.09.23 ADDED K10111 DD VERF:EC IPP REV:C
REDESIGN PER ENG ERROR 11-11-17 JLM VERIFIED BY:DD

Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Qty per Kit	Total Qty	Qty Issued	Date Issued	Status
---------------------------------	------------------------	---------------	-------------	---------------------	------------------	-----------------	--------------------	----------------	-------------	--------------	---------------	----------------	--------

D206-642-151

Manufactured

No

110

Each

1.0000

1

1

D206-642-151

Replacement Skidtube

**

50850

Location

Loc Qty

Loc Code

FG

1

77976

1

K10111

CH1703

Manufactured

No

110

Each

0.0000

1

1

K10111

Saddle, Skidtube 206

**

79570

W/O:		WORK ORDER CHANGES					
DATE	STEP	PROCEDURE CHANGE	By	Date	Qty	Approval Chief Eng / Prod Mgr	Approval QC Inspector

Part No: _____ PAR #: _____ Fault Category: _____ NCR: Yes No DQA: _____ Date: _____

Resolution: _____ Disposition: _____ QA: N/C Closed: _____ Date: _____

NCR:		WORK ORDER NON-CONFORMANCE (NCR)						
DATE	STEP	Description of NC Section A	Corrective Action Section B			Verification Section C	Approval Chief Eng	Approval QC Inspector
			Initial Chief Eng	Action Description Chief Eng	Sign & Date			

NOTE: Date & initial all entries